

GET THIS **LOOK**



GET THIS LOOK

SKILL LEVEL:
INTERMEDIATE



Equipment



- Heat Press

Garment



SanMar® — Sport-Tek® PosiCharge® Competitor™ Tee, Style ST350

SanMar® — Gildan® Youth Heavy Blend™ Crewneck Sweatshirt, Style 18000B

Wholesale Boutique™ — Viv & Lou® Halloween Tote, Style M970

Materials



- CAD-CUT® Glow
- CAD-CUT® Fashion-FILM®, Electric Orange & Black
- Glow-in-the-Dark Screen-Printed Transfer from Transfer Express®

Accessories



- Kraft Paper Cover Sheet
- 11"x15" Platen

How-To Instructions



Temperature: 305°F – 340°F degrees
Pressure: Medium

1. Load t-shirt onto heat press.
2. Preheat to remove moisture and wrinkles from garment.
3. Place screen-printed transfer.
4. Press at 340°F for 10 seconds.
5. Peel warm.
6. Load sweatshirt onto heat press.
7. Preheat to remove moisture and wrinkles from garment.
8. Place CAD-CUT® Glow.
9. Press at 305°F for 10-15 seconds.
10. Peel warm.
11. Place CAD-CUT® Fashion-FILM®
12. Press at 320°F for 15 seconds.
13. Peel hot.
14. Load tote onto heat press.
15. Place CAD-CUT® Fashion-FILM®.
16. Tack at 320°F for 3-5 seconds.
17. Peel hot.
18. Place CAD-CUT® Glow.
19. Press at 320°F for 15 seconds.
20. Peel warm.